

LIQUID LEVEL INDICATOR (LLi)

DESCRIPTION

The Liquid Level Indicator (LLi) provides a means of verifying the weight of agent in a container without having to remove the container and weigh it on a calibrated scale.


This device enables the inspector to determine the weight of agent with the container safely secured in its installed position.

LLi's are furnished on the 100, 150, 215, 375, 650 and 1000 lb. (44, 61, 88, 153, 267 and 423 L) containers.

- P/N 06-548 LLi Manual for ECARO-25® containers
- P/N 06-549 LLi Manual for FM-200 containers
- P/N 06-869 LLi Manual for FK-5-1-12 containers

Warning: The Liquid Level Indicator (LLi) **MUST** be installed while the Container is **EMPTY**.

| Container Size lb. (L) | LLi P/N |
|------------------------|------------|
| 100 (44) | 70-1353-27 |
| 150 (61) | 70-1353-14 |
| 215 (88) | 70-1353-18 |
| 375 (153) | 70-1353-27 |
| 650 (267) | 70-1353-38 |
| 1000 (423) | 70-1353-49 |



APPROVALS:

- UL Listed
- ULC Listed
- FM Approved



DATA SHEET

Form No.03-08 Issue No.21.0