

IMPULSE VALVE OPERATOR SUPERVISOR

DESCRIPTION

The Impulse Valve Operator Supervisor (IVOS) is used to monitor the presence of the Impulse Valve Operator (IVO). When installed between the Impulse Valve on the container and the IVO, this supervises the position of the actuation device; when the IVO is removed from the container this will cause a “trouble” at the system control panel.

This can also be used to monitor the position of the Impulse Valve Pneumatic Operator (IVPO).



APPROVALS:

- UL Listed
- FM Approved



SPECIFICATIONS

IMPULSE VALVE OPERATOR SUPERVISOR (IVOS) P/N 02-14263	
Switch	Normally Closed (Black) Normally Open (White) Common (Red)
Conduit	1/4" ID SST Flexible Conduit 33.5" lg. with 1/2" Knockout Connector
Wire Leads	22 AWG, 44" lg.

DATA SHEET

Form No.03-14 Issue No.21.0